

## ThunderCord mode-2 Charger







#### **Table of contents**

1	Safet	у	3		
	1.1	Intended use	3		
	1.2	Safety precautions	4		
2	Desci	ription of the product	5		
	2.1	Product appearance and dimensions	5		
	2.2	Product Overview	6		
	2.3 Main features of the product		7		
	2.4 Technical parameters		8		
3	Insta	Installation			
	3.1	Installation requirements	9		
	3.2	Security of the Charging Point	9		
	3.3	Installation environment requirements	10		
	3.4	SMART APP	11		
4	General Troubleshooting		15		
5	5 Maintenance		18		
	5.1	Service			
6	Disposal				
7	Warranty Policy19				
8	Declaration of Conformity20				

#### Copyright

The contents of this manual are protected by copyright and intellectual property laws. The content of this manual may only be copied, modified, reproduced or translated with express written permission from the manufacturer.



#### Safety

1

Disclaimer. The information provided is intended solely as a guideline and should not be considered as professional advice or an exhaustive representation of all applicable regulations. Users are encouraged to consult with qualified professionals and adhere to specific local, national, and international standards and regulations governing the installation and safety of charging points. Any reliance on the information provided is at the user's own discretion and risk. The entity providing this information shall not be held responsible for any consequences arising from its use or interpretation.

This manual has been translated into multiple languages. The original is written in UK English. All other languages are translations of the original. This manual may be modified without notification beforehand, please refer to our official website for the latest version of this manual.

#### 1.1 Intended use

This device is a mobile charger intended to charge electrical vehicles using power from a household power grid. The device may be used indoors and outdoors. The charging current can be adjusted to adapt to the availability of power at the charging location.

#### <u>This device must be used with specifications as per this manual.</u> <u>Safe use can only be guaranteed when the device is used as</u> <u>intended by this manual.</u>





#### 1.2 Safety precautions

Read all the safety precautions and instructions thoroughly before using the device. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious personal injury.

- Do not put fingers into the electric vehicle connector.
- Do not use the device when the cables are frayed, broken or otherwise damaged.
- Do not use this device if the enclosure is damaged, broken or otherwise damaged.
- Do not drop or bump the device.
- Do not store or use the device in environmental conditions that exceeds the conditions as stated in this manual.
- Do not remove the charging plug while the charging process is active. This may cause irreversible damage to the charger and the car.
- Do not modify the power plug or any other component.
- Do not use extension cords, multi-outlets power strips or similar products with this device.
- Do not immerse the device in water or other liquids. The device has limited dustproof and waterproof capabilities. the equipment has been flooded, immediately cut off the power and stop using it.
- The device is not serviceable, do not open the device.
- Use of any adapter with this product is not allowed.
- Only use the device with a properly grounded power outlet in compliance with local guidelines.
- During use, strictly follow this manual, otherwise the equipment may be damaged.
- Make certain the device is used in such a way that it will not be stepped on, tripped over or otherwise subjected to damage.
- The charger and cable can get warm during normal operation.
- The device should not be operated by children.





## 2 Description of the product

#### 2.1 Product appearance and dimensions





#### 2.2 Product Overview



- 1) Interchangeable power plug [OPTIONAL]
- 2) Plugs male end
- 3) Plugs female end
- 4) Wall bracket
- 5) Mode-2 charger
- 6) Vehicle connector
- 7) 7-14 Interchangeable power plug [OPTIONAL]



2.2.1 Equipped with LCD/LED status indication.

**2.2.2** The device has the function of controlling the current regulation and scheduling the charging times.

**2.2.3** With Wi-Fi/Bluetooth function, online current adjustment and charging appointment function can be realized through mobile phone APP.

2.2.4 System protection functions include:

- Overvoltage protection
- ✓ Undervoltage protection
- ✓ Overcurrent protection
- ✓ Short circuit protection
- ✓ Leakage protection
- ✓ Overtemperature protection
- ✓ Lightning protection

**2.2.6** A variety of different specifications of plugs, adapt to the socket standards of any country. Intelligent identification of adapter power and output current ensure the safety of equipment power.

**2.2.8** The shell is of a waterproof and dustproof design, with IP65 protection level, suitable for indoor and outdoor usage.



#### 2.4 Technical parameters

Input Type 1 Phase 3 Phase Max output power 3KW 7kW 11KW 22KW Input Voltage AC 240V AC 400V 50Hz/60Hz Input Voltage frequency **Output Voltage** AC 240V AC 400V **Output Current** 13A 32A 16A 32A **Output Power** The output power can be adjusted Efficiency ≥98 Insulation Resistance ≥10MΩ Idle Power Consumption ≤7W Type-A + DC 6mA RCD Working Temperature -30°C~+50°C Storage Temperature -40°C~+80°C **Ambient Humidity** 5%~95% No more than 2000 meters Altitude LED Indicator / LCD [Optional] Status Indicator 2.8 -inch LCD [Optional] **Display Screen** Wi-Fi 2.4GHz / Bluetooth Comm. Method **Charging System** IEC 61851, Mode 2 **Charging Port** IEC 62196, Type2 Protection class IP65 + IK10 Overvoltage, undervoltage, grounding, Safety Protections lightning, leakage, flame retardant shell, overcurrent, temperature control. **Energy Meter** ≥1.0 Level Weight Varies depending on cable length



# 3 Installation

Always comply with any applicable laws and regulations that have not been accounted for in this manual.

Make sure you have fully read, understand the instructions in this manual before attempting to install or use the device.

#### 3.1 Installation requirements

Choose the minimum cable diameter according to local legislations. <u>Minimum</u> recommendations up to 25 meters are:

Voltage	Amps [Up to]	Cable diameter [min.]
240	16	2.5 mm2
240	32	6 mm2
400	16	2.5 mm2
400	32	6 mm2

#### 3.2 Security of the Charging Point

The device must be installed according to the standard **IEC 61851-1 ed. 3**:

• Each charging point must be protected by its own residual current device (RCD) with a maximum rating of 30mA. This device may be installed either in the charging station or in the distribution board.

• Protection against DC fault currents must be provided, which can be achieved by using a type B residual current device. However, when implementing Type B, in some situations, other type B residual current devices may also need to be installed or replaced for selectivity reasons. Type B must comply with the above standards and with: NEN-EN-IEC 62423.

• In the event of a direct current (DC) fault exceeding > 6 mA, the installation must be disconnected.





#### 3.3 Installation environment requirements

**5.2.** The charger is a universal indoor and outdoor charger, which meets the IP65 protection level.

**5.2.2** Please ensure that the ambient temperature range of the installation site is within the allowable range of  $-30^{\circ}$ C to  $+50^{\circ}$ C.

**5.2.3** The installation site must be below 2000 meters above sea level.

**5.2.4** There should not be severe vibration and flammable and explosive materials near the installation site.

**5.2.5** The installation site should not be in low-lying areas or areas prone to water accumulation.

**5.2.6** The charger installation must be supported by the wall, if there is no wall support, it is recommended to use a special floor bracket for installation and fixation.

**5.2.7** When installing the charger body, ensure that the charger body is vertical, and the installation height ranges from the type-2 plug to the horizontal ground is between: 500~1500mm.





#### 3.4 SMART APP

The charger does <u>not</u> support 5GHz Wi-Fi network, you must confirm that the local Wi-Fi network is a **2.4GHz network**.

Download any TUYA-based APP from the APP store. For example, use one of the official TUYA APPs listed below:



- 1) Create an account or use the APP as a guest.
- 2) In the top right-hand corner. Press the  $\oplus$  symbol to add a new device.

ul 🗢	9:41 AM	\$100% 🔳
My Home -		ტ 🔂

3) Make sure the device is connected to mains power, but not inserted into a vehicle.



# 4) The APP will now search for the device, after it is found connect the device to the Wi-Fi network.

Adding device...

Ensure that the Wi-Fi signal is good.



- 5) The device is now added to the APP and can be used through the APP interface. Please keep in mind that the device will only work on the local Wi-Fi network, if the device is used on another location or network the APP won't connect to the charger. Use the buttons to control the device instead or reset the Wi-Fi connection.
- 6) Scan the code below in the TUYA APP to reset the Wi-Fi.





#### Interface overview



#### **Reset Wi-Fi**

In case the connection to the APP is lost the device can be reset and the APP connection can be made to a new account or Wi-Fi network.

LED model	LCD model		
Make sure the device is connected to mains power, but not			
inserted into a vehicle.			
Press both buttons 10 seconds			
Press right button "TIMER"	Press left button "CURRENT"		
Verify that the second row of	Coto "Uplink my Phone"		
lights (Numbers) are ON	Go to "Unlink my Phone"		
Press right button "TIMER" for at least 5 seconds to confirm			
Device will reboot and reset Wi-Fi			





LED model	LCD model			
Make sure the device is connected to mains power, but not				
inserted into a vehicle.				
Press left button "CURRENT" to select current level				
Press and hold left button for at least 2 second to confirm				
Timer				

LCD model			
Make sure the device is connected to mains power, but not			
inserted into a vehicle.			
Press and hold right button for at least 2 seconds			
Short press right button to			
select timer value			
Short press left button to			
enable or disable timer			

Press right button for at least 2 seconds to confirm

#### **Disable earth detection**

LCD model			
ected to mains power, but not			
o a vehicle.			
Press both buttons 10 seconds			
Press left button			
Go to "Cancel Ground			
Detection"			
east 5 seconds to confirm			
Device will set Ground Detection as requested			



# 4 General Troubleshooting

Fault	Possible causes	Solutions	
LED indiagtor or	Power not connected	Check that the power inlet is energized and that the power switch is closed.	
LED indicator or LCD does not light up	circuit breaker trips	Check the wiring and socket for improper connection or damage.	
	The device is damaged	Please contact the customer service center for repair	
Unable to start	The charging cable is not fully connected	Check whether the charging connector is plugged into the bottom of the socket	
charging	Protection circuit activated	Please refer to the RGB lamp control logic description.	
The charging current is less than the rated value	The vehicle malfunctions or is almost fully charged	It is normal for the charging current to drop when the vehicle's battery is nearly full.	





seq	STATE	Charging charger status	LED light	Remark
1	Norm	Standby	Blue light is always on	Normal state
2	Normal state	ready to charge state	Green light is always on	The connector is not activated.
3	te	Charging status	Flashing green light (on 500ms, off 500ms)	The connector is activated.
4		Charging completion status	Green light is always on	Stop charging when the car is fully charged or when the charging completion condition is reached.



seq	STATE	Charging charger status	LED light	Remark
5	Fai	Emergency stop	Red light blinks 1	
5	L	failure	time every 5s	
6	Fault state	Ungrounded fault / L and N reversed	Red light blinks 2 times every 5s	
7		CP error fault	Red light blinks 3	
/			times every 5s	
8		overcurrent fault	Red light blinks 4	
0			times every 5s	In case of
9		overvoltage fault	Red light blinks 5	failure, the red
3			times every 5s	light blinks ON
10		undervoltage	Red light blinks 6	for 200ms and
10		fault	times every 5s	OFF for 200ms.
11		Breaker sticking	Red light blinks 7	
		fault	times every 5s	
12		electric leakage	Red light blinks 8	
12		fault	times every 5s	
13		overtemperature	Red light blinks 9	
15		fault	times every 5s	
14		Faulty motor	Red light blinks 10	
14		Faulty meter	times every 5s	
			Red light on for	
15		Other faults	1000ms, off for	
			1000ms	





#### 5 Maintenance

The device is usually maintenance free. Only periodic cleaning of the housing and vehicle connector is required by the user.

- Switch off the device and remove it from any power source.
- Clean the device with a damp cloth.
- Do not use aggressive chemicals or flammable solvents.
- Do not use coarse cleaning tools, like abrasive pads, that may damage the surface.

#### 5.1 Service

The device is not serviceable by the user. If your charger is in need of service, please contact EVshield or your local vendor. Do not attempt to service, repair or modify the device in any way.

## 6 Disposal

If the device is defective beyond repair, or no longer used, please recycle the charger according to local rules, laws and guidelines regarding the disposal of electrical devices.





# ſ

# 7 Warranty Policy

The warranty period of this product is two years, starting from date of delivery. During the warranty period, the manufacturer will repair any malfunctions that are <u>not</u> caused by human error (as determined by an official employee); under normal use in accordance with this instruction manual.

The equipment is covered by the relevant warranty terms above except for the following issues :

- The purchase invoice cannot be provided, or the physical identification of the faulty device is altered or doesn't match the contents on the warranty certificate.
- 2) Beyond the warranty period specified.
- Damage caused by failure to use, maintain and store in accordance with the requirements of the product user manual.
- 4) Damage or malfunction caused by the entry of foreign objects, moisture, water or others.
- 5) Damage caused by disassembly.
- 6) Damage caused by force majeure (such as lightning, excessive voltage, earthquake, fire, flood, and other natural disasters).
- 7) Failure and damage caused by other unavoidable external factors.
- 8) Damage caused by improper use leading to water ingress or other solutions in the equipment.
- 9) Damage caused by using a power supply or voltage other than the specified one.
- 10) Damage as a result of not using the charger in conjunction with the EVshield.



24031701.1

#### **Declaration of Conformity**

EVshield® **EU DECLARATION OF CONFORMITY** 

#### Manufacturer: EVshield, a business unit of OMI-engineering.

This certifies that the following apparatus conforms to the requirements of the directives listed below

This declaration of conformity is issued under the sole responsibility of the manufacturer: **EVshield** Hagelkruis 49 5571PB Bergeiik The Netherlands

Description

8

ThunderCord

Applicable products



Reference 8720865767741 8720865767758 8720865767765

The object of the declaration described is in conformity with the relevant Union harmonisation legislation:

#### Standards Applied

#### Title

Directive 2011/65/EU of the European Parliament and of the Council on the restriction of the use of certain hazardous substances in electrical and electronic equipment.

Directive 2014/30/EU of the European parliament and of the council on the harmonisation of the laws of the Member States relating to electromagnetic compatibility

Directive 2014/35/EU of the European parliament and of the council on the harmonisation of the laws of the Member States relating to the making available on the market of electrical equipment designed for use within certain voltage limits

#### Reference

IEC 62321-4:2013+AMD1:2017, IEC 62321-5:2013, IEC 62321-6:2015, IEC 62321-7-1:2015, IEC 62321-7-2:2017, IEC62321-8:2017

EN IEC61000-6-1/2019 EN IEC 61000-6-3:2021, EN61851-21-1:2017/AC:2017-11, EN IEC 61851-21-2:2021

EN IEC 61851-1:2019, EN 62196-1:2014, EN62196-2:2017, EN62196-3:2014, EN 50620:2017/A1:2019. EN62752:2016/A1:2020. EN61984:2009, EN60998:2004, EN60730-1:2016/A2:2022, EN50470-1:2006/A1:2018, EN50470-3:2022

21-6-2024



Name: Position: Document: **Robin Bruil** Product designer 24031701



EVshield | www.EVshield.eu | Hagelkruis 49 5571PB Bergeijk | CoC: 84985186

Signature:

Date: Revision: